

PROCEDURE FOR FITTING CR2032 BATTERY IN V SERIES DIGITAL DIAL GAUGE

REMOVE BATTERY COVER



STEP 1



PLACE CR2032 BATTERY IN BATTERY COVER AND RE-INSERT IN DIAL GAUGE



STEP 2

NOTE : + TERMINAL OF BATTERY CR2032 FACES THE COVER SIDE

PROCEDURE FOR FITTING CR2032 BATTERY IN V SERIES DIGITAL DIAL GAUGE

REMOVE BATTERY COVER



STEP 1



PLACE CR2032 BATTERY IN BATTERY COVER AND RE-INSERT IN DIAL GAUGE



STEP 2

NOTE : + TERMINAL OF BATTERY CR2032 FACES THE COVER SIDE

PROCEDURE FOR FITTING CR2032 BATTERY IN V SERIES DIGITAL DIAL GAUGE

REMOVE BATTERY COVER



STEP 1



PLACE CR2032 BATTERY IN BATTERY COVER AND RE-INSERT IN DIAL GAUGE



STEP 2

NOTE : + TERMINAL OF BATTERY CR2032 FACES THE COVER SIDE